

# DSG Post TCU Tune Adaption

Credit: Original by FE\_Performance, Edits by AudiS7Reviews

After Every Transmission flash:

Transmission temperature MUST be 50-60 C

The engine must be running, and you have to have your foot on the brake firmly.

Do not use OBD11

1. Open VCDS
2. Select 02-Auto Trans
3. Select Basic Settings
4. Show Measurement Data
5. Select ATF Temperature
6. When your ATF has reached 50\*, click "Done Go Back"
7. Fully Depress Brake
8. Select the below IDE and hit go, waiting until they are done to move on to the next one.
9. IDE02294
10. IDE02295
11. IDE02298

(DO NOT DO THEM OUT OF ORDER)

Wait for each one to complete.

You'll need to drive around the city and highway for a bit to have everything calibrate.

---

Revision #1

Created 1 April 2025 22:23:31 by Deutsche Auto Garage

Updated 1 April 2025 22:23:42 by Deutsche Auto Garage