

Window Weld Mounts (DIY)

DIY UNDER CREATION - DO NOT ATTEMPT UNTIL THIS IS FINISHED OR DO SO AT YOUR OWN RISK

1. Drill out mount where fluid is contained in the mount.



2. Use a syringe to inject [3M Window Weld](#)

3. Let cure for 24-48 hours.

Failure to let it cure will likely result in part failure.

4. Re-install

Revision #2

Created 2025-04-01 22:37:28 UTC by Deutsche Auto Garage

Updated 2025-04-01 23:11:36 UTC by Deutsche Auto Garage