Window Weld Mounts (DIY)

> DIY UNDER CREATION - DO NOT ATTEMPT UNTIL THIS IS FINISHED OR DO SO AT YOUR OWN RISK

1. Drill out mount where fluid is contained in the mount.


AV2
PAL'S
0720

2. Use a syringe to inject 3M Window Weld
3. Let cure for 24-48 hours.

   > Failure to let it cure will likely result in part failure.

4. Re-install

Revision #2
Created 2025-04-01 22:37:28 UTC by Deutsche Auto Garage
Updated 2025-04-01 23:11:36 UTC by Deutsche Auto Garage