

VCDS Troubleshooting

I run Windows 11 and VCDS randomly stopped working:

(See screenshots below)


1. Go ahead and uninstall VCDS.


Check this:

Settings -> Update & Security -> Windows Security -> Device Security -> Core Isolation. Is "Memory integrity" turned on? If so, turn it off.

That "feature" uses virtualization and will likely prevent the driver from loading. It is generally off by default on most systems, but I wouldn't put it past Microsoft to have it on...

2. Once you've disabled this, you can download and re-install VCDS.





(Credit to D. Bui)

Revision #2

Created 2025-04-01 23:22:06 UTC by Deutsche Auto Garage

Updated 2025-04-01 23:24:21 UTC by Deutsche Auto Garage